

**WELCOME TO TECHNICAL ORDER 00-105E-9, 1 JULY 2004, REVISION 9.**

**THIS IS SEGMENT 7 COVERING CHAPTER 6 FROM THE VC-137 TO  
CHAPTER END.**

**TO NAVIGATE**

**CLICK ON THE  
BOOKMARKS AND  
CLICK ON THE (+)  
SYMBOLS, THEN  
CLICK ON SUBJECT  
LINKS TO GO TO  
SPECIFIC VIEWS  
IN THIS SEGMENT.**



**CONTINUE**

**NOTICE**

**CONTACT**

**TO GO DIRECTLY TO THE TECHNICAL ORDER,  
CLICK ON THE CONTINUE BUTTON.**

**TO SEE THE SEGMENT INFORMATION CHANGE NOTICE,  
CLICK ON THE NOTICE BUTTON.**



**TO CONTACT THE TECHNICAL CONTENT MANAGER ,  
CLICK ON THE CONTACT BUTTON.**

## TECHNICAL ORDER 00-105E-9 TECHNICAL CONTENT MANAGER

### WRITTEN CORRESPONDENCE:

HQ AFCESA/CEXF

ATTN: Fire and Emergency Services Egress Manager  
139 Barnes Drive Suite 1  
Tyndall AFB, Florida 32403-5319



E-MAIL: Tom.Stemphoski@tyndall.af.mil

INTERNET: HQ AFCESA Fire and Emergency Services PUBLIC WEB PAGE:  
<http://www.afcesa.af.mil/CEX/fire/index.asp>

PHONE: (850) 283-6150  
DSN 523-6150

FAX: (850) 283-6390  
DSN 523-6390

For technical order improvements, correcting procedures, and other inquiries, please use the above media most convenient.

## SEGMENT 7 INFORMATION CHANGE NOTICE

This page is provided to notify the user of any informational changes made to Technical Order 00-105E-9 in this Segment and the current Revision. Informational changes will be referenced in the Adobe Reader's Bookmark tool as a designator symbol illustrated as a <[C]> for quick reference to the right of the affected aircraft. The user shall insure the most current information contained in this TO is used for his operation. Retaining out of date rescue information can negatively affect the user's operability and outcome of emergencies. If the user prints out pages his unit requires, the user shall print the affected page(s), remove and destroy the existing page(s), and insert the newly printed page(s) in the binder provided for that purpose. A Master of this TO shall be retained in the unit's library for reference, future printing requirements and inspections.

<u>CHAPTER</u>	<u>AIRCRAFT</u>	<u>PAGE</u>	<u>EXPLANATION OF CHANGE</u>
6	KC-10	ALL	Add paint scheme page and placed aircraft dimensions on page 2, Rest of file re-paged.


## NOTE

Chapter 6 contains emergency rescue and mishap response information for the following aircraft:

USAF	C-5
USAF	C-7
USAF	(V)C-9A/C
USAF	C-12F
USAF	C-12J
USAF	C-17A
USAF	C-18
USAF	C-18D
USAF	C-20
USAF	C-20H
USAF	C-21
USAF	C-22B
USAF	C-23A
USAF	C-26
USAF	C-27A
USAF	C-32A
USAF	C-37A
USAF	C-38A
USAF	C-40
USAF	C-130
USAF	C-130J
USAF	C-135
USAF	C-135E
USAF	NKC-135E
USAF	OC-135B
USAF	RC-135S
USAF	RC-135U
USAF	RC-135V/W
USAF	TC-135S
USAF	TC-135W
USAF	WC-135W
USAF	(V)C-137
USAF	C-141
USAF	NC-141A
USAF	C-212
USAF	KC-10A

# AIRCRAFT SKIN PENETRATION POINTS

NOTE:  
Penetration points for the aircraft engines are identical regardless of position on the aircraft. Penetrate the engine cowling at the red points indicated.




(V)C-137.2 **AIRCRAFT SKIN PENETRATION POINTS-  
Continued**

**(V)C-137**

T.O. 00-105E-9


NOTE:

Penetrate through the center of any passenger window to access the aircraft cabin.



# AIRCRAFT HAZARDS

## ENGINE DANGER AREAS



# AIRCRAFT HAZARDS-Continued


## RADIATION HAZARD AREAS

### NOTE:

The radiation hazard area shown is around the weather radar antenna. Accidental entry into the hazard area does not result in injury. It is only through prolonged exposure that the possibility of danger exists.

 AREA HAZARDOUS TO PERSONNEL

 POSSIBLE FUEL IGNITION AREA



SPECIAL TOOLS/EQUIPMENT

- Power Rescue Saw
- 24 Ft Ladder
- Fire Drill II

AIRCRAFT ENTRY ALL MODELS

1. NORMAL ENTRY

- a. FORWARD AND AFT ENTRY DOORS - Pull external handle outward and rotate clockwise, then push inward on forward side of door, pull outward on aft side and swing door out and forward.
- b. FORWARD AND AFT GALLEY DOORS - Pull external handle outward and rotate clockwise, then push inward on forward side of door, pull outward on aft side and swing door out and forward.

2. EMERGENCY ENTRY

- a. Push in panel on emergency exit hatches, two each side above wing, and push hatches inward.

CAUTION

Emergency exit hatches must be handled with extreme care while pushing hatches inward.


3. CUT-IN

- a. Cut-in emergency exit hatches located top forward center of fuselage over wings.

NOTE:  
\*FUEL TANKS FOR VC-137C


\*\*FUEL TANKS FOR VC-137B

ALL FUEL IN US GALLONS



(V)C-137


NOTE:  
Aircraft Dimensions  
Length 152' 11"  
Wing Span 145' 9"  
Height 42' 5"



# ENGINE SHUTDOWN

## 1. ENGINE SHUTDOWN

- a. Place engine thrust lever friction handle, located on control stand, to forward position, then retard engine thrust levers aft to IDLE position.
- b. Place engine start levers, located on lower portion of control stand, down to CUTOFF position.
- c. Pull fire emergency T-handles, located upper center of instrument panel, and place engine fuel shutoff valve switches, located on fuel system panel at engineer's station, to CLOSE position.
- d. Place battery switch, located on engineer's upper panel, to OFF position.





# APU SHUTDOWN

## 2. APU SHUTDOWN

### NOTE:

The following procedures are only used if an APU fire is apparent.

- a. If fire warning light is indicating APU fire, the APU can be shutdown from the navigator's control panel or the APU compartment in the aft cargo compartment.
- b. There are two designs at the navigator's panel. Both designs are illustrated. Place fire extinguisher switch, located at center of panel to OFF.
- c. Place master switch, located upper left on panel to OFF.



# AIRCREW EXTRACTION

## SEATING AND POSITIONING

### 3. AIRCREW EXTRACTION

**NOTE:**

Pilot's seat is shown, copilot's seat is identical except controls are on left side.

**NOTE:**

Flight engineer's seat will face within 30 degrees of forward for takeoff and landing.


- a. Release lap and remove shoulder harness from crewmembers.

**NOTE:**


If seat tracks are not damaged during crash landing, use adjustable seat controls to retract seat to aft position.

- b. Adjust seats for ease of extraction.

- c. Release lap belts from passengers.



FLIGHT ENGINEER'S SEAT




PILOT'S/COPILOT'S SEAT

# AIRCREW EXTRACTION-Continued

## SEATING AND POSITIONING 3. AIRCREW EXTRACTION-Continued

NOTE:  
Navigator/CSO seat will face within 30 degrees of forward for takeoff and landing.

NOTE:  
The ACM seat can be tilted forward 25 degrees and latched in either the full forward or full back position. The forward tilt is used only to gain access to the locking mechanism that secures the seat to the cabin floor.






# OXYGEN SHUTOFF

## 4. OXYGEN SHUTOFF


### NOTE:

The oxygen system is divided into two separate and independent subsystems: flightcrew and passenger oxygen system. The crew oxygen system is a demand-type system supplying supplemental and protective oxygen to crewmembers whenever flight altitude exceeds 10,000 feet. Protective and emergency oxygen is also available to the crewmembers from a portable oxygen bottle located in the control cabin. In addition, portable oxygen bottles for first aid and cabin attendant use during cabin decompression are located in the passenger cabin.


- If the oxygen system is required to be shutoff during an emergency, turn off the passenger oxygen switch, located on the pilot's overhead panel, to OFF.
- Turn off the crew oxygen switch, located on the navigator's control panel, to OFF.
- Manual shutoff valves are physically located on the top of each oxygen cylinder. Use if the above controls (steps a,b) can not be accessed. Valves are located at the forward and aft cargo compartments on the right side.




4c  
MANUAL  
SHUTOFF  
VALVES



A



B




C

C-141.1 **AIRCRAFT SKIN PENETRATION POINTS**

**C-141**

T.O. 00-105E-9

NOTE:  
Penetration points are identical for all engines.  
Engine nacelles (inboard side) access door at  
approximately power plant station 70.



**AIRCRAFT HAZARDS****WARNING**


Flares are a source of ignition for many of the lubricants and fluids used in servicing aircraft. Selected aircraft have a Countermeasures Dispensing System or flare dispensing capabilities. These devices are located in FL 520 and FS 1130E on both sides of the aircraft. Avoid looking in the direction of the burning or detonating magnesium incendiaries. Stray voltage can cause ignition. Personnel should ground themselves prior to approaching these critical areas.

Affected Tail numbers:

64-619  
 64-649  
 65-266  
 65-269  
 65-273  
 65-279  
 65-618  
 65-0271  
 66-174  
 66-196  
 66-202  
 67-0012  
 67-0026

C-141 Special Operations Low Level  
 (SOLL):

66-131  
 67-0014



## SPECIAL TOOLS/EQUIPMENT

Power Rescue Saw  
24 Foot Extension Ladder  
Fire Drill II

## NOTE:

Aircraft Dimensions  
Length 158' 4"  
Wing span 159' 11"  
Height 39' 3"

## AIRCRAFT ENTRY ALL MODELS

## 1. NORMAL ENTRY-CREW DOOR, TROOP DOORS


- a. Pull T-handles, one forward left side and two aft, one on each side of fuselage, out and rotate clockwise.

## 2. EMERGENCY ENTRY

- a. Press emergency exit release triggers, rotate handle counterclockwise and push hatch, located one forward and one aft wing root each side, inward.
- b. Lift release ring and pull upward to open emergency exits, located top left forward of flight deck, top forward and aft of cargo compartment.
- c. Strike rectangular bump plate, located above and inboard of hatch, to open.

## 3. CUT-IN

- a. Cut-in areas located aft of left forward emergency exit and aft of both troop doors.




# ENGINE/APU SHUTDOWN AND AIRCREW EXTRACTION

## 1. ENGINE/APU SHUTDOWN

- a. Pull engine fire control T-handles, located upper center portion of instrument panel.
- b. Pull APU fire T-handle, located on flight engineer's panel.
- c. Place battery switch, located on flight engineer's electrical panel, to OFF position.



1a  
ENGINE FIRE CONTROL T-HANDLES




1b  
APU FIRE T-HANDLE


## 2. AIRCREW EXTRACTION

- a. Raise seat armrest and unlatch lap belt(s) and remove shoulder harness from crewmember(s).
- b. If tracks are not damaged during crash landing, use adjustable seat control handles on four forward seats only to retract seats in aft position to aid in removing crewmember(s).

2a  
RAISED ARMREST



2b  
FORWARD/AFT POSITION CONTROL HANDLE




2a  
RAISED ARMREST

2a  
CENTER RELEASE FOR SAFETY BELTS AND SHOULDER HARNESS



2b  
FORWARD/AFT POSITION CONTROL HANDLE

1c  
BATTERY SWITCH



# C-141.5 OXYGEN SHUTOFF VALVE LOCATIONS

C-141

T.O. 00-105E-9


**NOTE:**

- Three valves: one on flight deck and two in cargo compartment.
- Cargo compartment valves: near aircraft station #830 cargo bulkhead-right side 24" above cargo deck, 45' from normal crew entry door two valves in small compartment with door, troop seats may block the valves.
- Flight deck valve: pilot's left console, near thigh area (valve is painted red and is round).

OXYGEN CONVERTER


TWO VALVES IN CARGO COMPARTMENT NEAR STATION #830

ONE VALVE ON FLIGHT DECK PILOT'S LEFT CONSOLE, RED, ROUND VALVE



PILOT'S SIDE CONSOLE



(LOOKING DOWN AND OUTBOARD)



COPILOT'S SIDE CONSOLE



CARGO COMPARTMENT LOOKING FORWARD



# AIRCRAFT ENTRY

## NOTE:

The NC-141A is an UNSTRETCHED or original version of the C-141.

1. NORMAL ENTRY (NC-141A 61-2775 THRU 61-2777)


### WARNING

The aircraft must be completely depressurized before either the inside or outside door handle is operated. Opening doors or hatches while the aircraft is pressurized could cause serious injury to personnel.

- a. Open external handle access panel, located center of crew entry and troop entrance doors.
- b. Rotate external release handle downward the full length of its travel.
- c. Pull door out and up, then lower manual securing arm, located on the lower inside aft corner of the door, and secure to a fitting on the door frame.

## NOTE:

Emergency entry and cut-in procedures are the same on all C-141 aircraft.



# TEST BED CONFIGURATION

## TAIL NUMBER: 61-2775

## TEST PILOT SCHOOL

PASSENGER CAPACITY: 126.

ADDITIONAL OXYGEN BOTTLES: NO.

LOX Converters: 25 liter converter located in the nose landing gear wheel well left hand side.


Nitrogen Bottles: NO.

Modified Escape Routes: NO.


Changes for Engine/APU Shutdown: NONE.

Changes in Electrical/Battery Power: This aircraft is equipped with a Class II Test Master Power Switch, located at the Flight Engineer's panel right side, which will disable all modification power without disturbing main aircraft power. See visual aid that is applicable to all NC-141A models.

HINDRANCES/DIFFERENCES: This aircraft is a pre-production aircraft. The forward entrance hatch opens outward. Extreme caution must be exercised to ensure aircraft has been depressurized prior to opening hatch. Failure to comply will cause injury or death to personnel if the door is blown open by cabin pressure.



FLIGHT ENGINEER PANEL WITH CLASS II TEST MASTER POWER SWITCH



# TEST BED CONFIGURATION

## TAIL NUMBER: 61-2776

### TEST PILOT SCHOOL

PASSENGER CAPACITY: 60.

ADDITIONAL OXYGEN BOTTLES: NO.

LOX Converters: 25 liter converter located in the nose landing gear wheel well left hand side.


Nitrogen Bottles: NO.

Modified Escape Routes: NO.

Changes for Engine/APU Shutdown: NONE.

Changes in Electrical/Battery Power: This aircraft is equipped with a Class II Test Master Power Switch, located at the Flight Engineer's panel right side, which will disable all modification power without disturbing main aircraft power. See visual aid that is applicable to all NC-141A models.

HINDRANCES/DIFFERENCES: This aircraft is a pre-production aircraft. The forward entrance hatch opens outward. Extreme caution must be exercised to ensure aircraft has been depressurized prior to opening hatch. Failure to comply will cause injury or death to personnel if the door is blown open by cabin pressure.



# TEST BED CONFIGURATION

## TAIL NUMBER: 61-2777

### TEST PILOT SCHOOL

PASSENGER CAPACITY: 65.

ADDITIONAL OXYGEN BOTTLES: NO.

LOX Converters: 25 liter converter located in the nose landing gear wheel well left hand side.

Nitrogen Bottles: NO.


Modified Escape Routes: NO.

Changes for Engine/APU Shutdown: NONE.

Changes in Electrical/Battery Power. This aircraft is equipped with a Class II Test Master Power Switch, located at the Flight Engineer's panel right side, which will disable all modification power without disturbing main aircraft power. See visual aid that is applicable to all NC-141A models.

HINDRANCES/DIFFERENCES: This aircraft is a pre-production aircraft. The forward entrance hatch opens outward. Extreme caution must be exercised to ensure aircraft has been depressurized prior to opening hatch. Failure to comply will cause injury or death to personnel if the door is blown open by cabin pressure.

NC-141A



# TEST BED CONFIGURATION

## TAIL NUMBER: 61-2779

### TEST PILOT SCHOOL

PASSENGER CAPACITY: 18

**ADDITIONAL OXYGEN BOTTLES:** This aircraft has two 75 liter liquid oxygen converters located in the right main landing gear wheel well.

**LOX Converters:** 25 liter converter located in the nose landing gear wheel well left hand side.

**Nitrogen Bottles:** Gaseous nitrogen located in the nose landing gear wheel well right hand side.


**Modified Escape Routes:** NO.

**Changes for Engine/APU Shutdown:** NONE.


**Changes in Electrical/Battery Power:** NONE

This aircraft is NOT equipped with a Class II Test Master Power Switch.

**HINDRANCES/DIFFERENCES:** This aircraft is a production aircraft. The forward entrance hatch opens to the outside. The floor plan is very congested. This aircraft is modified with three different non-standard radomes, (B-1, F-15, F-16) which may be flown at any given time.



- |  |   |
|--|---|
| 1. ARTB RADAR ANTENNA HYDRAULIC SUB-SYSTEM                                 | 10. MAIN TEST EQUIPMENT POWER DISTRIBUTION JUNCTION BOX |
| 2. AVIONICS VIDEO MONITOR  | 11. RADAR TEST BENCH                                    |
| 3. COLOR VIDEO CAMERA  | 12. TARGET GENERATOR/APTEC COMPUTER RACK                |
| 4. NOSE SECTION ARTB RADAR EQUIP COOLING/PRESSURIZATION DUCTS              | 13. VAX COMPUTER RACK                                   |
| 5. WEATHER RADAR   | 14. TELEMETRY RACK                                      |
| 6. SCNS INU  | 15. POWER CONTROL AND MONITORING PANEL                  |
| 7. ENGINE GENERATOR OVERRIDE AND POWER TRANSFER PANEL                      | 16. ARTB STATIC INVERTERS                               |
| 8. NOSE SECTION ARTB RADAR EQUIP COOLING/PRESSURIZATION FLT STA AIR INTAKE | 17. VIDEO RACK  |
| 9. GPS BATTERY   | 18. TEST ARTICLE/TEST ENGINEER CONSOLE                  |
|  | 19. TEST DIRECTOR/INSTRUMENTATION ENGINEER CONSOLE      |
|  | 20. ESM/INSTRUMENT COMPUTER OPERATOR CONSOLE            |
|  | 21. OBSERVERS STATION CONSOLE                           |



**OXYGEN SYSTEM LEGEND:**

1. FILLER
2. COMBINATION FILL-BUILDUP-VENT VALVE
3. OVERBOARD VENT
4. LIQUID OXYGEN CONVERTER
5. HEAT EXCHANGER
6. MANUALLY OPERATED SHUTOFF VALVE



- LINE VALVE
- PORTABLE UNIT STOWING PROVISIONS
- PORTABLE UNIT
- PORTABLE UNIT RECHARGER
- MASK PULG-IN OUTLET
- WARNING HORN (LOW OXYGEN QUANTITY WARNING AND BAILOUT SIGNAL)
- HEAT EXCHANGER (WARMING COIL) REGULATOR

- LOW QUANTITY WARNING LIGHT
- QUICK DISCONNECT
- MASK REGULATOR TUBING
- THERAPEUTIC OXYGEN BOX

- ELECTRICAL LINE
- FILLER LINE
- DISTRIBUTION LINE
- WIRE BUNDLE, CONVERTER TO QUANTITY INDICATOR

## SPECIAL TOOLS/EQUIPMENT

Power Rescue Saw  
12 Ft Ladder  
Fire Drill II

## NOTE:

Dimensions:  
Length 53'  
Height 21' 6"  
Wing Span 66' 5"

C-212


## AIRCRAFT ENTRY

## 1. NORMAL ENTRY

- a. One passenger access door is located in the rear left side of the main cabin. The door opens inward and to the rear.
- b. Two crew access doors are symmetrically located in the front of the main cabin, opening outward and forward.

## 2. EMERGENCY ENTRY


- a. One emergency door is located in the rear right side of the main cabin. Opposite side is passenger door that can be accessed.
  - b. One roof escape hatch is located in the front fuselage.
  - c. Two rear side windows located at front fuselage are of the sliding type to be used as an emergency exit for the pilots.
  - d. Rear cargo door opens inward and is hydraulically operated. If hydraulic system is inoperative, do not try to operate cargo door during rescue procedures.
3. CUT-IN
- a. Cut in and penetrate skin as needed.



# ENGINE SHUTDOWN

## 1. ENGINE SHUTDOWN

- a. Retard feathering levers, located on overhead console, aft to the shut-off position.
- b. Switch engine shutdown switches, located on overhead console, to the OFF position.
- c. Switch master switch, located on overhead console, to the OFF position.
- d. If engine fire has been detected (see WARNING light), activate Fire Extinguishing System. There are two discharge switches for each engine.



# AIRCREW EXTRACTION AND SEATING, CABIN, AND CARGO CONFIGURATIONS

## 2. AIRCREW/TROOP EXTRACTION


- a. Aircrew seats are equipped with shoulder harnesses and lap belts.
- b. Troop seats are fitted with safety belts only.
- c. Use applicable configuration for extraction.

### SEATING, CABIN, CARGO CONFIGURATIONS


PARACHUTISTS/PARATROOPERS 25




COMBINED CARGO-LIGHT VEHICLE




COMBINED PASSENGER/CARGO




SANITARY 12 STRETCHERS +4 MEDICAL ASSISTANTS




REMOTE AREAS SUPPORT




MARITIME PATROL




ENGINE TRANSPORT




LAPES



PHOTOGRAPHIC



NAVIGATION SCHOOL






# AIRCRAFT DIMENSIONS

NOTE:  
Fuselage width: 19 FT 9 IN or 6.02 Meters.

VERTICAL CLEARANCE						
	NOMINAL CLEARANCE MAXIMUM RAMP WEIGHT NOMINAL CENTER GRAVITY		MINIMUM CLEARANCE CRITICAL WEIGHT AND CENTER GRAVITY		MAXIMUM CLEARANCE CRITICAL WEIGHT AND CENTER GRAVITY	
	FT - IN.	METERS	FT - IN.	METERS	FT - IN.	METERS
A	27-2	8.28	27-1	8.25	28-1	8.56
B	6-1	1.85	5-10	1.78	6-10	2.08
C	57-7	17.55	57-2	17.42	58-7	17.86
D	10-9	3.28	10-8	3.25	11-10	3.61
E	9-8	2.95	9-7	2.92	10-6	3.20
F	7-9	2.36	7-9	2.36	8-5	2.57
G	2-11	0.89	2-10	0.86	3-7	1.09
H	14-6	4.42	14-4	4.37	16-3	4.95
I	23-10	7.26	23-5	7.14	24-10	7.57
J	36-10	11.23	36-7	11.15	37-8	11.48



KC-10A.3 **AIRCRAFT SKIN PENETRATION POINTS**

**KC-10A**

T.O. 00-105E-9

Note:


A firewall separates the fan and core engine compartments.

AFT ENGINE (BOTH SIDES)  
CORE COWL DOOR, PENETRATE  
2.5 FOOT AFT OF LEADING  
EDGE OF DOOR AT 3 O'CLOCK  
AND 9 O'CLOCK POSITION


AFT ENGINE (BOTH SIDES)  
FAN COWL DOOR, PENETRATE  
1 FOOT FORWARD OF TRAILING  
EDGE OF DOOR AT 3 O'CLOCK  
AND 9 O'CLOCK POSITION


RIGHT ENGINE (BOTH SIDES)  
CORE COWL DOOR, PENETRATE  
2.5 FOOT AFT OF LEADING  
EDGE OF DOOR AT 3 O'CLOCK  
AND 9 O'CLOCK POSITION

RIGHT ENGINE (BOTH SIDES)  
FAN COWL DOOR, PENETRATE  
1 FOOT AFT OF LEADING EDGE  
OF DOOR AT 3 O'CLOCK  
AND 9 O'CLOCK POSITION



# AIRCRAFT SKIN PENETRATION POINTS-Continued







# AIRCRAFT CONFIGURATIONS

20-PERSONNEL: CODE G

# KC-10A





KC-10A.7 **AIRCRAFT CONFIGURATIONS-Continued**

**KC-10A**

T.O. 00-105E-9


EXPANDED CONFIGURATION: CODE D  
 ADDITIONAL CREW: 6 SEATS  
 SUPPORT PERSONNEL: 69 SEATS



# PORTABLE EMERGENCY EQUIPMENT LOCATIONS


LEGEND:

- HALON 1211 GAS TYPE EXTINGUISHER (9 PLACES)
- ◇ GASEOUS EXTINGUISHER (2 PLACES)
- SMOKE GOGGLES (2 PLACES)
- ⊠ FLASH LIGHT (3 PLACES)
- 11 CU FT OXYGEN CYLINDER/CREW MASK (2 PLACES)
- ⊕ 11 CU FT OXYGEN CYLINDER/PASSENGER MASK (14 PLACES)
- ⊕ FIRST AID KIT (4 PLACES)
- ⚡ CRASH AXE (4 PLACES)



# PERSONNEL EVACUATION AND SLIDE ARRANGEMENT


# KC-10A



**PASSENGER CONFIGURATION**

GROUND ESCAPE DOOR


ARO COMPARTMENT HATCH



**CARGO CONFIGURATION**

GROUND ESCAPE DOOR

ARO COMPARTMENT HATCH



CLEARVIEW WINDOWS

CLEARVIEW WINDOWS

ADDITIONAL SUPPORT PERSONNEL KIT INSTALLATION

**SPECIAL TOOLS/EQUIPMENT**

- Power Rescue Saw
- 1/4-In. Speed Handle Wrench
- 35 Ft. Ladder
- Fire Drill II

**AIRCRAFT ENTRY**

**WARNING**

Keep clear of all entry doors during opening. Overwing and aft left doors are bolted shut. Do not attempt to ingress or egress from these areas.

**1. NORMAL ENTRY**

- a. Pull door control handle out of recess to disarm escape slide.
- b. Move door control switch to open and hold.
- c. When door is fully open, release switch.

**2. EMERGENCY ENTRY**

**NOTE:**

When emergency entry is used, door will automatically move to full open position under pneumatic pressure.


- a. Pull door control handle out of fuselage.
- b. Rotate emergency override level from safe position to emergency position and hold.
- c. Rotate door control handle to emergency position.

**IF DOOR STILL DOES NOT OPEN**

**WARNING**

Forward cabin doors have slide/rafts attached and are very heavy. Required lifting force may exceed 400 lbs. Mid cabin doors may or may not have slide/rafts installed.

- d. Push door inward as far as possible and hold.
- e. Use any available means to pry door upward.



# AIRCRAFT ENTRY-Continued

## 3. MANUAL ENTRY

- a. Pull door control handle out, rotate to free fall position and hold.
- b. Insert 1/4 inch drive into socket and rotate as indicated until door is open.

CAUTION

Torque applied in excess of 100 IN-LB or 500 RPM may result in damage.

- c. Release door control handle to neutral.



## 4. CUT-IN

- a. Cut-in areas are located at normal entries and areas marked.

**MANUAL DRIVE**

1. PULL HANDLE OUT
2. ROTATE HANDLE TO FREE FALL
3. INSERT 1/4" SQUARE DRIVE INTO SOCKET AND ROTATE AS INDICATED
4. MAXIMUM OPERATING TORQUE = 100 IN. LBS. AT 500 RPM

3b  
LEFT FORWARD DOOR ONLY




# ENGINE SHUTDOWN

## 1. ENGINE SHUTDOWN

- Retard throttles, located on pilot's center console, full aft position.
- Place fuel control levers, located on pilot's center console, aft and down to full detent.
- Place APU fire control switch, located on flight engineer's left panel to OFF position.
- Place battery switch, located on flight engineer's upper left panel, in OFF position.

### NOTE:

- If engines fail to shutdown, push emergency fire T-handles, located on pilot's overhead panel, forward.
- APU can be shut off from ground control panel, located just aft of left landing gear wheel well fairing fillet.



# AIRCREW EXTRACTION

## 2. AIRCREW EXTRACTION

- a. Two emergency evacuation slide/rafts are provided at the forward cabin doors.

**NOTE:**

When airplane is arranged for maximum passenger configuration two additional slide/rafts will be installed at the mid cabin doors.


- b. Escape ropes are installed adjacent to each pilot's openable clearview window and one escape rope is installed at the right rear cabin door.

**NOTE:**

- Access can be gained to the flight crew compartment through electronics compartment located in nose section, and through nose wheel well pressurized door.
  - Access to the ARO compartment can be effected through the aft right side cabin door and down the access ladder.
- c. Release personnel restraints by: Rotating quick release knob on lap belt and remove shoulder harness. Pull seat manual release handle to adjust seat to a recline position when removing crew-members.

**NOTE:**

Passenger seats are equipped with lap belts only.



PERSONNEL RESCUE DATA	
LOCATION	MAXIMUM CREW/PAX
FLIGHTDECK	5
PAX COMP	75
ARO COMP	3 (not normally occupied during takeoff/landing)

# AIRCREW SEATING

## PILOT AND COPILOT'S SEATS

### INFLATABLE BACK SUPPORT

When seated, press control valve button on lower edge of backrest cushion, and support automatically assumes lumbar contours of occupant. When control button is released, back support will retain contours. When seat is unoccupied, press control button and support will return to fully inflated position.

### ARMREST RELEASE (2)

Flush fingertip control on bottom of armrest releases lock to permit adjustment. The inboard armrest may be swiveled around behind seat back from stowed position to provide additional space for entering or leaving seat.

### POWER CONTROL HANDLE


Placing the four-position handle to FWD, AFT, UP, or DOWN position will move seat in direction of handle movement. When seat is in full outboard and aft position (for exit), placing handle in FWD position will first move the seat inboard the forward. Handle is spring-loaded to the center position.

### SEAT CONTROLS

Shown upside-down for clarity.


### EXIT CONTROL BUTTON

When pushed the button operates the electric motor to move the seat aft and outboard for exit from cockpit. Seat must be moved full aft (and the First Officer's seat back must be near the vertical position) before it can be moved outboard.




# AIRCREW SEATING-Continued

FLIGHT ENGINEER SEAT



# AIRCREW SEATING-Continued


ARO SEATS AND SEAT POSITIONING



**VERTICAL SEAT POSITION SIGHTING**  
 Adjust seat vertically until adjustment track of aft viewing periscope mirror appears to be a tunnel.

**HORIZONTAL SEAT POSITION SIGHTING**  
 Adjust seat horizontally so operator line of sight is parallel with upper surface of instrument panel glare shield.

**AIR REFUELING OPERATION AND SEATING ARRANGEMENT**




**FORWARD/AFT CONTROL LEVER (ROTATED 180 DEGREES)**

# AIRCREW SEATING-Continued

## BOOM OPERATOR AND CREWMEMBER/OBSERVER SEATS

**INFLATABLE BACK SUPPORT**  
 When seated, press control valve button on lower edge of backrest cushion, and support automatically assumes lumbar contours of occupant. When control button is released, back support will retain contours. When seat is unoccupied, press control button and support will return to fully inflated position.

**ARMREST RELEASE (2)**  
 Flush fingertip control on bottom of armrest releases lock to permit adjustment.



**CREWMEMBER/OBSERVER'S SEAT**  
 Shown in the extended position. Normally spring loaded in stowed position.

**SEAT CONTROLS (S, V, H)**  
 Controls release seat for manual adjustment to desired position.

**CAUTION**  
 DO NOT LIFT VERTICAL CONTROL HANDLE UNLESS SEAT IS OCCUPIED.

# CARGO DOOR OPERATION

## NOTE


- On aircraft 79-0433 and 79-0434, the CARGO DOOR SYS (A and B) lights, located on the flight engineers upper instrument panel No. 2, go off when the cargo door is closed and locked.
- On aircraft 79-1710 and subsequent, the CARGO DOOR SYS B light goes off when the cargo door is closed and locked. The CARGO DOOR SYS A light goes off only when both the cargo door and vent door are closed and locked.


## MANUAL LATCH CONTROLS

- To Open: Open vent door.
- Pull lockpin handle up to UNLOCK and hold.
- Insert hydraulic hand pump handle in latch actuating socket and push down to UNLATCHED position.
- Release lockpin handle.
- To Close: Insert hydraulic hand pump handle in latch actuating socket and pull up to LATCHED position. Lockpin handle will return to LOCK position.
- Close vent door.

**CAUTION**


Check lockpin handle and latch actuating socket are in lock position and main cargo door annunciator light is off after each latching operation.






**FWD** VIEW A  
LOOKING INBOARD

PULL  
HANDLE




VIEW B  
VENT DOOR MECHANISM



**CAUTION**



STOW PIP  
PIN IN CLIPS  
WHEN OPERATING  
CARGO DOOR



VIEW C

# CARGO DOOR OPERATION-Continued

## NOTE:

The following procedures are contained on the CARGO DOOR HYDRAULIC CONTROL PANEL.

Instructions to operate the upper cargo door.  
(Door latches at 85° and 165° only.)

**CAUTION**


Baggage racks and interior panels in the area of the main cargo door must be removed before opening.

## TO CLOSE DOOR

1. Pull control handle up and hold
2. Rotate control handle to "OPEN" until door is raised above latch. Then rotate handle directly to "CLOSE" and hold until door closes and latches.
3. Release control handle and stow in clip before securing access door.
4. Close and lock cargo vent door per instruction placard on door.
5. See placard on inside of cargo door for pip pin installation instructions.


## TO OPEN DOOR

1. If installed, remove pip pin and stow in clips provided.
2. Open cargo vent door per instruction placard on door.
3. Lift control handle from clip to upright position.
4. Pull control handle up and hold.
5. Rotate control handle to "OPEN" and hold until door is above either latching point (85° to 165°).
6. Release control handle.
7. (For 85° position only) rotate control handle to "CLOSE" until door rests on mechanical latch. Do not pull control handle up during this operation.



# FLIGHT CREW OXYGEN SYSTEM

LOCATION AND SHUTOFF





# FIRE PROTECTION-CONTROLS AND INDICATORS

FLIGHT ENGINEER'S UPPER PANEL NO. 1

**APU FIRE Light (Summary)**  
 Indicates APU fire warning circuit is activated. APU LOOPS A and dB lights. F/E's MASTER WARNING, and APU FIRE lights and pilot's MASTER WARN lights are on. Automatic APU shutdown occurs when light comes on. Horn sounds for ground notification.


**MASTER WARN Light (2)**  
 Comes on when the APU FIRE lights are activated.



**CAB CARGO SMOKE Light**  
 Comes on when the cabin cargo smoke circuit is activated or tested. The pilot's MASTER CAUTION lights and CAB CARGO SMOKE light, the flight engineer's MASTER CAUTION flight engineer's MASTER CAUTION and CAB CARGO SMOKE lights, and one or more CABIN CARGO SMOKE DETECTORS — lights are on.




**ENGINE FIRE Light**  
 Comes on when engine fire warning system is activated. Pushing the cap turns off the engine fire warning light on the glareshield, silences the alarm bell, and rearms the engine fire warning system. Pushing the cap does not turn off the engine fire warning light in the engine fire handle.



**MASTER WARNING Light**  
 Comes on when the APU FIRE lights are activated.

**APU FIRE AGENT CYL Switch (1,2)**  
 Momentarily moving either switch to DISCH discharges respective agent container to APU compartment if APU fire control switch is in APU OFF AGENT ARM.  
 NOTE: Only 2 fire agent containers are available to APU.



**APU FIRE Light**  
 Indicates APU fire detection system is energized. Pilot's MASTER WARN and APU FIRE summary lights and F/E's MASTER WARNING light are on. Automatic APU shutdown occurs when light comes on.  
 NOTE: Battery bus must be powered for all APU operations to arm APU fire detection system.



**APU FIRE CONTROL Switch**  
 APU OFF AGENT ARM — Shuts down APU arms fire control system, and deenergizes APU generator field.  
 NORM — Provides electrical power for latching F/E's APU FIRE warning light on.



# FIRE PROTECTION-CONTROLS AND INDICATORS

KC-10A

## THROTTLE QUADRANT

### AGT LOW Light (1,2)

Indicates that fire extinguishing agent in respective cylinder has been discharged. Engine 2 (and APU) AGENT LOW Light 1 and 2 are powered by battery bus.

### ENG FIRE Handle (1, 2, 3)

Shuts off electrical power, alarm bell, fuel and hydraulic supply and, when pulled full forward and rotated, discharges agent into selected engine nacelle.

**GEN FIELD DISCONNECT** - De-energizes respective generator field and silences alarm bell if not already silenced by respective ENGINE FIRE light.

**FUEL & HYD OFF** - Shuts off respective fuel and hydraulic supply, and positions engine fire handle to permit rotation for agent discharge into selected nacelle.


Twisting engine fire handle while pulling handle may result in premature firing of extinguishing agent.

### ENGINE FIRE Light

Comes on when engine fire warning system is activated. Pushing light turns off light, silences alarm bell, and rearms engine fire warning system. Pushing light does not turn off ENG FIRE warning light in engine fire handle.

### Fuel Lever Light (3)

The light in fuel lever comes on when respective engine fire warning light (in engine fire handle) is activated. Indicates which fuel lever to shut off. With engine fire handle pulled and fuel lever ON or OFF the light remains on if fire warning still exists. With engine fire handle pulled and fire warning terminated, light remains on until fuel lever is moved to OFF position.




OVERHEAD PANEL

**ENG FIRE Warning Light (1, 2, 3)**  
Comes on to indicate that overheat or fire has been detected in the associated engine nacelle.




GLARESHIELD



PEDESTAL

# FIRE PROTECTION CONTROLS SCHEMATIC

FIRE CONTROL PANELS



A = AMBER  
R = RED