

TO 00-25-172CL-3

**TECHNICAL MANUAL
CHECKLIST**

**HOT REFUELING OF U.S. NAVY
AIRCRAFT**

This manual supersedes TO 00-25-172CL-3 dated 22 October 1990, Change 4 dated 22 April 2013.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited. PA Case Number 04-10-74. Other requests for this document shall be referred to 406 SCMS/GUEE, Robins AFB, GA 31098. Questions concerning technical content shall be referred to HQ AFMC/SEG.

Published Under Authority of the Secretary of the Air Force

28 OCTOBER 2016

LIST OF EFFECTIVE PAGES

INSERT LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

NOTE The portion of the text affected by the changes is indicated by a vertical line in the outer margin of the page. Changes to illustrations are indicated by shaded or screened areas, or by miniature pointing hands.

Dates of issue for original and changed pages are:

Original . . . 0 . . . 28 October 2016

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 68, CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.
Title	0		
A	0		
i - ii	0		
iii - viii	0		
1-1 - 1-5	0		
1-6 Blank	0		
1-7	0		
1-8 Blank	0		
2-1 - 2-7	0		
2-8 Blank	0		
3-1 - 3-7	0		
3-8 Blank	0		
4-1 - 4-4	0		
5-1 - 5-7	0		
5-8 Blank	0		
6-1 - 6-7	0		
6-8 Blank	0		
7-1 - 7-13	0		
7-14 Blank	0		

* Zero in this column indicates an original page.

TABLE OF CONTENTS

Chapter	Page
FOREWORD	iii
SAFETY SUMMARY	vii
1 SUPPORT EQUIPMENT FOR HOT REFUELING OPERATIONS	1-1
2 EA/A-6 HOT REFUELING PROCEDURES	2-1
2.1 EA/A-6 HOT REFUELING PROCEDURES	2-1
3 E-2 HOT REFUELING	3-1
3.1 E-2 HOT REFUELING	3-1
4 F-14 HOT REFUELING PROCEDURES	4-1
4.1 F-14 HOT REFUELING PROCEDURES	4-1
4.1.1 Aircraft Fuel Dump (Jettison) Outlet	4-1
4.1.2 Refueling	4-1
5 EF/F-18 HOT REFUELING PROCEDURES	5-1
5.1 EF/F-18 HOT REFUELING PROCEDURES	5-1
5.1.1 Fuel Dump Outlets	5-1
5.1.2 Self-Start	5-1
6 S-3 HOT REFUELING PROCEDURE	6-1
6.1 S-3 HOT REFUELING PROCEDURE	6-1
6.1.1 Auxiliary Power Unit (APU)	6-1
6.1.2 Refueling	6-1

TABLE OF CONTENTS - CONTINUED

Chapter		Page
7	AV-8 HOT REFUELING PROCEDURES	7-1
7.1	REFUELING/DEFUELING	7-1

FOREWORD

1 PURPOSE.

In a wartime situation, United States (US) Navy aircraft may land at United States Air Force (USAF) bases to refuel on its way to home base or carrier. The Navy aircraft may need to be hot refueled (i.e., refueled with an engine running) in order to minimize ground turnaround time and avoid the need for support equipment. This checklist provides the procedures for hot refueling Navy aircraft. Applicable aircraft are the EA/A-6, A-7E, E-2, F-14, EF/F-18, S-3 and AV-8. The E/A-6, E-2, F-14, and S-3 aircraft will shut down the right engine for hot refueling. The EF/F-18 has been approved to hot refuel with both engines running. This checklist is a step-by-step guide to accomplish the selected tasks. Although many details are present, this checklist is intended for use by fully qualified and trained hot refueling personnel only.

2 SCOPE.

The following support equipment is required to follow the procedures set forth in this checklist:

- Fuel Source (R5/R9/R11/R12 Fuel Truck, Hydrant Fuel Pit, or Fuel Bladders)
- Grounding and Bonding Wires
- Fire Extinguisher, 150 pound Halon, or Equivalent
- Crash/Fire/Rescue Vehicle
- M32A-60 Power Cart, or Equivalent (For E-2 Aircraft Only)
- Eye Protection (For E-2 Aircraft Only)
- Hand Signalling Wands (For Night Operations)
- Chocks
- Intercom Cord with Adaptors (If available)

3 ABBREVIATIONS.

All abbreviations used in this manual are shown in the list of abbreviations below. Standard abbreviations are in accordance with ASME Y14.38, Abbreviations and Acronyms for Use on Drawings and Related Documents.

TO 00-25-172CL-3

AF	Air Force
AFTO	Air Force Technical Order
APU	Auxiliary Power Unit
ARFF	Aircraft Rescue and Firefighting
DLA	Defense Logistics Agency
DoD	Department of Defense
ESDS	Electrostatic Discharge Sensitive
ETIMS	Enhanced Technical Information Management System
HCI	Hardness Critical Items
HRS	Hot Refueling Supervisor
ITER	Improved Triple Ejector Rack
JFS	Jet Fuel Starter
lbs	pounds
No.	Number
PSI	pound-force per square inch
SN	Serial Number
SPR	Single Point Receptacle
SPRM	Single Point Receptacle Monitor
TCTO	Time Compliance Technical Order
TO	Technical Order
TOMA	Technical Order Management Agency
US	United States
USAF	United States Air Force

4 RELATED PUBLICATIONS.

NOTE

When searching technical order (TO) numbers in the Enhanced Technical Information Management System (ETIMS) catalog, please use the wildcard (*) after typing in the TO number. Many TOs are not available in paper format, (i.e., digital (WA-1) or Compact Disk (CD-1)). This ensures TOs in all media formats will populate the search.

The following publications contain information in support of this technical manual.

List of Related Publications

Number	Title
ASME Y14.38	Abbreviations and Acronyms for Use on Drawings and Related Documents
DODI 5330.03_AFI 33-395	Defense Logistics Agency (DLA) Document Services
TO 00-5-1	AF Technical Order System
TO 00-25-234	General Shop Practice Requirements for the Repair, Maintenance, and Test of Electrical Equipment
TO 00-25-172	Ground Servicing of Aircraft and Static Grounding/Bonding

5 RECORD OF APPLICABLE TIME COMPLIANCE TECHNICAL ORDERS (TCTOs).

List of Time Compliance Technical Orders

TCTO Number	TCTO Title	TCTO Date
----------------	---------------	--------------

None

6 **HCI** HARDNESS CRITICAL ITEMS (HCI).



The HCI symbol (**HCI**) establishes special requirements limiting changes and substitutions and that the specific parts listed must be used to ensure hardness is not degraded.

If included, items with nuclear survivability requirements are marked with the HCI symbol (**HCI**). All changes to, or proposed substitutions of, HCIs must be approved by the acquiring activity.

TO 00-25-172CL-3

7 ELECTROSTATIC DISCHARGE SENSITIVE (ESDS) ITEMS.



All ESDS parts shall be handled in accordance with the ESDS device handling procedures in TO 00-25-234.

If included, items containing ESDS parts are marked with the ESDS symbol ().

8 CHANGE RECOMMENDATIONS.

Recommendations proposing changes to this technical order shall be submitted on an Air Force Technical Order (AFTO) Form 22 in accordance with TO 00-5-1. Forward completed AFTO Form 22 to the Technical Order Management Agency (TOMA) at: robins.ce.afto22@us.af.mil.

SAFETY SUMMARY

1 GENERAL SAFETY INSTRUCTIONS.

This manual describes physical and/or chemical processes which may cause injury or death to personnel, or damage to equipment, if not properly followed. This safety summary includes general safety precautions and instructions that must be understood and applied during operation and maintenance to ensure personnel safety and protection of equipment. Prior to performing any specific task, the WARNINGS, CAUTIONS, and NOTES included in that task shall be reviewed and understood.

2 WARNINGS, CAUTIONS, AND NOTES.

WARNINGS and CAUTIONS are used in this manual to highlight operating or maintenance procedures, practices, conditions, or statements which are considered essential to protection of personnel (WARNING) or equipment (CAUTION). WARNINGS and CAUTIONS immediately precede the step or procedure to which they apply. WARNINGS and CAUTIONS consist of four parts: heading (WARNING, CAUTION, or icon), a statement of the hazard, minimum precautions, and possible results if disregarded. NOTES are used in this manual to highlight operating or maintenance procedures, practices, conditions, or statements which are not essential to protection of personnel or equipment. NOTES may precede or follow the step or procedure, depending upon the information to be highlighted. The headings used and their definitions are as follows:

**WARNING**

Highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in injury to, or death of, personnel or long term health hazards.



Highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in damage to, or destruction of, equipment or loss of mission effectiveness.

NOTE

Highlights an essential operating or maintenance procedure, condition, or statement.

CHAPTER 1

SUPPORT EQUIPMENT FOR HOT REFUELING OPERATIONS

GENERAL PRECAUTIONS.

- a. Hot refueling will only be done by properly trained and qualified personnel.
- b. Only United States Air Force (USAF)-approved hot refueling equipment will be used.
- c. Do not hot refuel aircraft with a hot brake condition.
- d. Prior to hot refueling, all external tanks, stores, and weapons must be safed.
- e. The Base Fire Chief will determine the location that the standby Aircraft Rescue and Firefighting (ARFF) will be postured.
- f. The maximum refueling pressure is 55 pound-force per square inch (PSI).
- g. Verify with the aircrew that fuel has not been dumped (jettisoned) on the previous flight. If fuel had been dumped and the position of the dump valve is not positively known to be closed, then aircraft will not be hot refueled.
- h. Intercom will be used if available. Otherwise, the hand signals in Figure 1-1 will be used.
- i. Aircraft high level shutoff valves must be pre-checked at the beginning of the hot refueling operation. If an aircraft fails any pre-check, the aircraft can only be cold refueled.
- j. During hot refueling, check that air is flowing from the aircraft fuel vent outlet(s) (except EF/F-18). Navy external tank vents are on the bottoms of the external tanks.

TO 00-25-172CL-3

- k. If sufficient grounding receptacles are not available, attach a grounding clamp to any unpainted metal surface.
- l. Avoid the tail hook area (bottom of fuselage near the aft end).
- m. Do not touch any pitot tubes or probes which may be hot.
- n. Avoid the areas underneath external tanks or stores until they are safed.
- o. Many United States (US) Navy hot refueling operations employ the use of emergency dry-break disconnect devices for rapid taxi away in emergencies. USAF bases do not use this device, so NAVY pilots must be advised beforehand on current USAF hot refueling emergency procedures.

REFUELING SIGNALS

1. TOP OFF




PAT TOP OF HEAD.

2. FUEL STATUS




MOVEMENT OF THUMB TO MOUTH FOR REQUESTING FUEL ON BOARD.

3. PROBE OUT



ARM ACROSS CHEST, THEN EXTEND OUT HORIZONTALLY.

4. PROBE IN PROBLEM



ARM EXTENDED OUT HORIZONTALLY, THEN BROUGHT IN TO CROSS CHEST.

5. CLOSE DUMP VALVE



POINT FINGER AT ELBOW.

6. CUT FUEL




FINGERS POINT AT THROAT, MOVING HAND SIDWAYS.

TO-00-25-172CL-3-001


Figure 1-1. Navy Hand Signals (Sheet 1 of 3)

FUEL QUANTITY SIGNALS *

FOR HUNDREDS OF POUNDS




FOR EVEN THOUSANDS OF POUNDS



FOR LOADS THAT DO NOT FALL ON EVEN THOUSANDS OF POUNDS

EXAMPLE: 1,500 LBS


EXAMPLE: 7,400 LBS




DOUBLE FINGER (A VERTICAL SIGNAL FOLLOWED BY A HORIZONTAL ONE)

FOR LOADS OF TEN THOUSANDS OF POUNDS AND OVER

EXAMPLE:
12,000 LBS




EXAMPLE:
12,500 LBS



DOUBLE FINGER (A VERTICAL SIGNAL FOLLOWED BY A HORIZONTAL ONE) FOLLOWED BY A CLENCHED FIST FOR EXACT THOUSANDS, OR A THIRD FINGER SIGNAL FOR HUNDREDS.

Figure 1-1. Navy Hand Signals (Sheet 2)

SIGNALS



HOT BRAKES

DAY	NIGHT
<p>MAKES RAPID FANNING MOTION WITH ONE HAND IN FRONT OF FACE AND POINTS TO WHEEL WITH OTHER HAND.</p>	<p>SAME AS DAY EXCEPT WITH WANDS.</p>
<p>REMARKS</p>	

TO-00-25-172CL-3-003

Figure 1-1. Navy Hand Signals (Sheet 3)

EMERGENCY PROCEDURES.

- a. If a fire or fuel leak occurs at the aircraft:
 - (1) Stop fuel flow at the source.
 - (2) Notify the aircrew of the emergency and to stop aircraft engine(s) and Auxiliary Power Units (APUs).
 - (3) Notify the fire department.
 - (4) Evacuate all personnel (including the aircrew other than fire guards).
 - (5) If leak: Fire guards will stand by with portable extinguisher nozzles in hand until the fire department arrives.
 - (6) If fire: Fire guards will attempt to extinguish the fire until fire department arrives or until munitions are engulfed in flame (in this case, immediately withdraw at least 4000 feet).

- b. If a fire occurs at another location in the area:
 - (1) Stop fuel flow at source and at the nozzle.
 - (2) Disconnect nozzle, intercom, and ground wires. Remove chocks.
 - (3) Signal the aircrew to taxi the aircraft clear of the area.
 - (4) Fire guards will assist in fire fighting until the fire department arrives.

CHAPTER 2

EA/A-6 HOT REFUELING PROCEDURES

2.1 EA/A-6 HOT REFUELING PROCEDURES.

The Single Point Receptacle (SPR) is located on the lower part of the right engine nacelle about 2.5 feet aft of the engine inlet. The fueling control panel (station) is immediately aft of the right nacelle boarding ladder at approximately eye level. Figure 2-1 shows the refueling station switches that control fuel flow into the three fuselage tanks, five wing tanks, and up to four external tanks. Total internal fuel capacity is 2344 gallons; each external fuel tank holds an additional 300 gallons. Aircraft fuel dump outlets are located on the wing trailing edges near the wingtips and at the aft end of the fuselage. Fuel vent outlets are located in the aft fuselage and on the undersides of the wings near the wingtips. (The wingtip vents are used only when the wings are folded). Three fuel tank over-pressurization lights are located on the fueling station door to warn of impending fuel tank over-pressurization. The aircraft has no on board Auxiliary Power Unit (APU) or self-start capability, but one engine can start the other. The A-6 aircraft SPR panel receives electrical power from the right engine only, so A-6 aircraft cannot be hot refueled at United States Air Force (USAF) bases until the entire fleet is modified to provide electrical power to the SPR panel from the left engine. EA-6 aircraft can be hot refueled with the right engine shut down because the left engine can provide electrical power to the SPR panel.


CURSORY INSPECTION.

WARNING

- Do not hot refuel following aerial refueling operations until a positive check has been made to ascertain the aerial refueling probe has not been damaged. Failure to comply could result in injury to, or death of, personnel or long term health hazards.
 - During refueling, tank overpressure indicator lights on the fueling station door must be monitored to prevent rupture of the fuel tanks. If one or more of these lights illuminate during fueling, refueling must be stopped immediately and the cause of the overpressure must be corrected before refueling may be resumed. Failure to comply could result in injury to, or death of, personnel or long term health hazards.
 - Only EA-6 aircraft can be hot refueled at USAF bases. Failure to comply could result in injury to, or death of, personnel or long term health hazards.
- a. Stop the aircraft at least 50 feet short of the hot refueling area.
 - b. Signal the aircrew to shut down the right engine.
 - c. Check for hot brakes.
 - d. Verify all weapons, external tanks and stores have been safed. If they have not been safed, open the left crew access ladder door and remove the pins from the storage compartment. Install the pins.
 - e. Verify the fuel dump (jettison) valve is closed.
 - f. If aerial refueling operations have occurred since the last ground refueling, visually inspect the bullet shaped plug at the end of the refueling probe to ascertain that the bullet plug is properly aligned with the probe. An angle alignment indicates the plug is not prop-

erly seated and that a fuel spill is likely to occur during the refueling cycle. Do not proceed with hot refueling, if the bullet plug is not properly aligned.

- g. Signal the aircrew to spread wings.
- h. Signal the aircrew to taxi to the hot refueling area.



TO-00-25-172CL-3-004

Figure 2-1. A-6 Fueling Station Panel

REFUELING.

- a. Position the aircraft on the hot refueling pit.
- b. Chock and ground (clamp) the aircraft.
- c. If available, connect the intercom (usually at the SPR panel).
- d. Ensure DUMP circuit breaker (on nose wheel well circuit breaker panel) is engaged (A-6 only).
- e. Prior to refueling, check that no air is flowing from the external fuel tank vents (on the bottom of the external tanks). This verifies that engine bleed air is not pressurizing the tanks.
- f. On the FUELING STATION panel, set the POWER switch to FUEL, and set the WING TANKS, FUS TANKS, and DROP TANKS switches to FUEL.



If the indicators checked in Step g and Step h malfunction, do not refuel the aircraft. Failure to comply could result in damage to, or destruction of, equipment or loss of mission effectiveness.

- g. On the fueling station access door, press the OUTER HIGH PRESS indicator FUSELAGE HIGH PRESS, INNER HIGH PRESS, and OUTER HIGH PRESS lights should illuminate; if not, stop refueling.
- h. On the FUELING STATION panel, momentarily press each WING TANKS, FUS TANKS, and DROP TANKS indicator that is not lighted; each indicator should illuminate when pressed; if not, stop refueling.
- i. Ground the refueling equipment and bond to the aircraft.

WARNING

Prior to pressurizing the fuel source, verify the nozzle is locked onto the aircraft by attempting to remove the nozzle with the flow handle open. If you can remove the nozzle, do not start the refueling until the nozzle is replaced. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- j. Remove the dust cap from the fueling adapter and connect the fueling nozzle to the adapter and open the flow handle. Attempt to remove the nozzle with the flow handle in the open position.
- k. Start fueling the aircraft; immediately set and hold the SOL CHECK switch to PRI. All WING TANKS PRI, FUS TANKS PRI, and DROP TANKS PRI indicators should go out and fueling automatically stop prior to the aircraft receiving 45 gallons of fuel (10 to 15 seconds). If this does not occur, discontinue the fueling operation.
- l. When the fuel flow stops, check flow rate. If the flow rate exceeds 3 gallons or 20 pounds per minute, shut off the fueling unit and disconnect the fuel nozzle.
- m. On the FUELING STATION panel, set the DROP TANKS switches to HOLD and release the SOL CHECK switch.
- n. When the fuel flow starts, immediately set and hold the SOL CHECK switch to SEC. All WING TANK SEC and FUS TANKS SEC indicators should go out and fueling will automatically stop prior to aircraft receiving 30 gallons or 200 pounds of fuel. If this does not occur, discontinue the fueling operation.
- o. When the fuel flow stops, check flow rate. If the flow rate exceeds 3 gallons or 20 pounds per minute, shut off the fueling unit and disconnect the fuel nozzle.
- p. On the FUELING STATION panel, set the WING TANKS switches to HOLD and release the SOL CHECK switch.

- q. Check the aerial refueling probe for leaking.
- r. Check for airflow from the fuel vents. (Airflow should be present as the tanks fill.)



If any of the three high pressure indicators illuminate during the fueling, fueling must be stopped immediately and the cause of the vent system overpressure corrected before the fueling is resumed. Failure to comply could result in damage to, or destruction of, equipment or loss of mission effectiveness.

- s. Fuel the fuselage tanks until the FUS TANK indicators on the FUELING STATION panel go out.
- t. On the FUELING STATION panel, set the WING TANKS switches to FUEL. On aircraft with external fuel tanks, set the DROP TANKS switches to FUEL. When the WING TANKS, FUS TANKS, and DROP TANKS indicators are all out, the aircraft is refueled.
- u. On the FUELING STATION panel, set the POWER switch to OFF.
- v. Shut off the fueling unit and disconnect the nozzle. Replace the dust cap on the fueling nozzle adapter.
- w. Close and secure the FUELING STATION door.
- x. Disconnect the intercom and the grounding/bonding cables.
- y. Remove the safety pins and replace in the boarding ladder stowage compartment.
- z. Remove the chocks and direct the aircrew to taxi away from the area.

CHAPTER 3

E-2 HOT REFUELING

3.1 E-2 HOT REFUELING.

The Single Point Receptacle (SPR) and refueling control panel (Figure 3-1) are located on the inboard side of the right engine nacelle. The NOT FULL lights illuminate to indicate fuel is flowing into the tank. The pre-check will test both the primary and secondary floats in each high level shutoff valve. Fuel is carried in two wing tanks with a total capacity of 824 gallons. There are no external fuel tanks or weapons. The fuel vent and dump outlets are at the extreme aft end of the fuselage. If a tank overfills, the vent system cannot handle the excess flow, so the fuel will spray from one of the fuel tank relief valves on top of the wing at the outboard end of the fuel tank. This sprayed fuel might reach an engine exhaust, so to further prevent overfilling, refuel flow must be stopped when the pilot signals a tank has reached 200 pounds less than full. The aircraft has no on board Auxiliary Power Unit (APU) and except for newer models, one engine cannot start the other. Therefore, a ground power cart is needed.

CURSORY INSPECTION.

WARNING

The E-2 is a turboprop aircraft. Be constantly aware of the rotating propellers. Do not walk forward of the wings unless you are outboard of the wingtips. Due to propwash, the Single Point Receptacle Monitor (SPRM) must wear eye protection. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- a. Stop the aircraft at least 50 feet short of the hot refueling area.

WARNING

- Due to the crash fire rescue limitations with E-2 aircraft with wings folded, this aircraft will not be hot refueled unless the wings are in the fully extended position. Failure to comply could result in injury to, or death of, personnel or long term health hazards.
 - Ensure the area is clear prior to spreading (unfolding) the wings. Failure to comply could result in injury to, or death of, personnel or long term health hazards.
- b. Signal the aircrew to spread the wings.
 - c. Check for hot brakes. When moving from one wheel to the other, walk to the wingtips prior to going forward. Walk well in front of the aircraft.
 - d. Verify the fuel dump (jettison) valve is closed.
 - e. Signal the aircrew to shut down the right engine.
 - f. Signal the pilot to taxi to the hot refueling area.

REFUELING.

- a. Position the aircraft on the hot refueling pit.
- b. Chock and ground the aircraft. (Grounding receptacles are located near the SPR and on the right center fuselage at eye level.)



Avoid the cooling fan on the fuselage, just inboard of the SPR. Failure to comply could result in damage to, or destruction of, equipment or loss of mission effectiveness.

- c. Open the PRESS FUE STA access door (inboard side of right engine nacelle) and check the left and right strainer bypass lights. If either is illuminated, signal the aircrew to shut down the left engine, and notify aircrew of the situation.
- d. Ground the refueling equipment and bond to the aircraft. Route the refueling equipment behind the right main landing gear.



Prior to pressurizing the fuel source, verify the nozzle is locked onto the aircraft by attempting to remove the nozzle with the flow handle open. If you can remove the nozzle, do not start refueling until the nozzle is replaced. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- e. Remove the dust cap from the pressure fueling adaptor, and connect the fueling nozzle. Rotate the nozzle flow handle to the open position and attempt to remove the nozzle.
- f. Begin the fueling. Both NOT FULL lights should illuminate indicating that fuel is entering the tanks.
- g. Hold the left TANK PRE-CHECK switch to PRIM. After the left NOT FULL LIGHT goes out (approximately 3 seconds later) hold the right TANK PRE-CHECK switch to SEC. After the right NOT FULL LIGHT goes out, the fueling should terminate, if this does not occur, discontinue the refueling operation. If fuel flow stops, release the switches and continue fueling.

- h. Hold the left TANK PRE-CHECK switch to SEC and the right TANK PRE-CHECK to PRIM. If fuel flow does not stop when NOT FULL lights go out, turn off fueling source immediately and disconnect pressure fueling nozzle.

WARNING

Because failure of a fuel shutoff valve could result in fuel being sprayed from the fuel tank pressure relief valve (on top of the wing above each nacelle) onto the hot exhaust area of the tailpipe, the possibility of causing a fire exists. Hot refueling must be stopped when either tank reaches 200 pounds less than full. Failure to comply could result in injury to, or death of, personnel or long term health hazards.


- i. Continue refueling. SPRM will monitor the NOT FULL lights and the Hot Refueling Supervisor (HRS) will watch attentively the aircrew for the cutoff signal, and release the deadman control immediately when the cutoff signal is received.
- j. When the fuel flow is stopped, shut off the refueling unit and disconnect the nozzle. Install the dust cap. Remove the fueling equipment.
- k. Close and secure the PRESS FUE STA access door.
- l. If needed, connect the M32A-60 or equivalent air/power source air hose to the ground air start station (inside the right main landing gear wheel well).

WARNING

Avoid the rotating propeller. Failure to comply could result in injury to, or death of, personnel or long term health hazards.


- m. Signal the aircrew to start the right engine.
- n. Disconnect the power cart and remove from the aircraft.

- o. Remove the grounding/bonding wires.
- p. Remove the chocks and signal the pilot to taxi away from the area.



TO-00-25-172CL-3-005

Figure 3-1. E-2 Refueling Provisions (Sheet 1 of 2)



TO-00-25-172CL-3-006

Figure 3-1. E-2 Refueling Provisions (Sheet 2)

CHAPTER 4

F-14 HOT REFUELING PROCEDURES

4.1 F-14 HOT REFUELING PROCEDURES.

The Single Point Receptacle (SPR) is on the right side of the fuselage at eye level and 16 feet forward of the right engine inlet. The SPR panel (Figure 4-1) includes a REFUEL/TRANSFER switch, two pre-check switches (FUS TANKS and WING/EXT TANKS) and a fuel vent pressure gauge. The fuel vent pressure gauge consists of a pointer on a scale having a green (safe) band and a red (danger) band. The aircraft has eight fuselage fuel tanks two wing box tanks, two integral wing tanks, and two external fuel tanks. Total internal capacity is 2385 gallons, while each external tank holds 267 gallons.

4.1.1 Aircraft Fuel Dump (Jettison) Outlet. The aircraft fuel dump (jettison) outlet is located on the boat tail between and forward of the engine exhausts. The internal fuel tanks are vented through an outlet on the bottom of the fuselage just forward of the tail hook pivot. The external fuel tanks are vented through outlets on the tank bottoms.

4.1.2 Refueling. The aircraft has no on board auxiliary power unit or selfstart capability, but either engine can start the other. Refueling can be done with the wings swept forward or aft.

CURSORY INSPECTION.

- a. Stop the aircraft at least 50 feet short of the hot refueling area.
- b. Signal the aircrew to shut down the right engine.
- c. Check for hot brakes.
- d. Verify all weapons and external tanks have been safed. The external tanks use integral safing levers (Figure 4-1) instead of pins.
- e. Verify the fuel dump (jettison) valve is closed.
- f. Signal the aircrew to taxi to the hot refueling area.

REFUELING.

- a. Position the aircraft on the hot refueling pit.
- b. Chock and ground (clamp) the aircraft.
- c. Prior to refueling, check that no air is flowing from the external fuel tank vents (on bottom of the external tanks). This verifies that engine bleed air is not pressurizing the tanks.
- d. Open the SPR panel door (on the right fuselage).
- e. Ground the refueling equipment and bond to the aircraft. (Use the grounding receptacle at the SPR panel.)
- f. If available, connect the intercom (in nose wheel well).

WARNING

Prior to pressurizing the fuel source, verify the nozzle is locked onto the aircraft by attempting to remove the nozzle with the flow handle open. If you can remove the nozzle, do not start refueling until the nozzle is replaced. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- g. Remove the dust cap from the SPR adaptor, connect the fueling nozzle, and open the flow handle. Attempt to remove the nozzle with the flow handle in the open position.

CAUTION

If the pre-checks do not automatically stop fuel flow, do not hot refuel the aircraft. Failure to comply could result in damage to, or destruction of, equipment or loss of mission effectiveness.


- h. Verify DEFUEL/TRANSFER switch is in the NORM position.

- i. Begin the fuel flow.
- j. Pre-check the refuel system. Place both selector valves to the STOP FUEL position at the same time. Fuel flow should stop within 30 seconds. If this does not occur, discontinue the refueling operation.
- k. Place both selector valves to the FUEL position, and continue the refueling.
- l. Check for air flow from the fuel vents, airflow should be present as the tanks fill. Avoid the tail hook area.

WARNING

Monitor the fuel vent pressure indicator and stop the refueling if the pressure indicates in the red band (above 4 pound-force per square inch (PSI)). Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- m. Monitor the vent pressure indicator during the refueling operation.
- n. When the fuel flow stops (tanks filled), shut off the fuel source and disconnect the nozzle.
- o. Remove the grounding/bonding wires and the intercom.
- p. Unsafe the external tanks.
- q. Close and secure the SPR panel.
- r. Remove the chocks and signal the aircrew to taxi away from the area.



TO-00-25-172CL-3-007

Figure 4-1. F-14 SPR

CHAPTER 5

EF/F-18 HOT REFUELING PROCEDURES

5.1 EF/F-18 HOT REFUELING PROCEDURES.

The Single Point Receptacle (SPR) is on the right side of the forward fuselage about 17 feet forward of the right engine inlet. Figure 5-1 shows the SPR panel which includes precheck switches, a rotating fuel flow indicator, and a tank pressure gauge (with a green safe zone and a red danger zone). F-18C/D aircraft also include a REFUEL TEST switch (which will not be used during hot refueling) and a VENT TANK WET light with a test switch.

5.1.1 Fuel Dump Outlets. The fuel dump outlets are on the trailing edges of the vertical stabilizers, while the external tanks have their own vents at the tank bottoms. Total internal fuel capacity (in four fuselage tanks and two wet wing tanks) is 1589 gallons. Each of three external tanks carries 315 or 330 gallons.

5.1.2 Self-Start. The aircraft has a self-start capability provided by an on board Jet Fuel Starter (JFS) which is not operated during refueling.

CURSORY INSPECTION.

- a. Stop the aircraft at least 50 feet short of the hot refueling area.
- b. Check for hot brakes.
- c. Verify all weapons and external tanks have been safed. Ensure the external fuel tank safety select (Figure 5-2) is in the LOCKED position.
- d. Verify the fuel dump (jettison) valve is closed.
- e. Signal the aircrew to taxi to the hot refueling area.

REFUELING.

- a. Position the aircraft on the hot refueling pit.

- b. Chock and ground the aircraft. Use an approved grounding clamp on an unpainted surface.

WARNING

When the right engine is operating, keep all personnel and refueling equipment at least 15 feet from the engine intake. Do not allow the right engine to be operated above the idle power setting. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- c. Open the SPR door Number (No.) 8 on the right side of the forward fuselage and remove the SPR dust cap.
- d. If available, connect the intercom (near SPR).
- e. Check that no air is flowing from the external fuel tank vent outlets (on the bottom of the tanks). This verifies that the engine bleed air is not pressurizing the tanks.
- f. Ground the refueling equipment and bond to the aircraft using the grounding receptacle in the SPR panel.

WARNING

Prior to pressurizing the fuel source, verify the nozzle is locked onto the aircraft by attempting to remove the nozzle with the flow handle open. If you can remove the nozzle, do not start the refueling until the nozzle is replaced. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- g. Connect the nozzle to the SPR adaptor and open the nozzle flow handle. Attempt to remove the nozzle with the flow handle in the open position.

- h. (F-18C/D only.) Press the VENT TANK SNSR TEST switch and observe the VENT TANK WET light illuminate. If the light fails to illuminate, do not hot refuel the aircraft.
- i. Begin fuel flow and place the red master pre-check handle to the UP PRE-CHECK position.
- j. Approximately 30 seconds later, place the external fuel tank pre-check switches to the pre-check positions:
 - (1) On F-18A/B Serial Number (SN) 161353 through SN 161761, press and hold the L, R, and C, F TK CHECK switches.
 - (2) On F-18A/B SN 161924 and up, press and hold the EXT TX PRCHKSW.
- k. On F-18C/D, press and hold the EXT TANK PRE CHK switch to pre-check.
- l. Fuel flow should stop 10 to 30 seconds later (check the fuel flow indicator). If the fuel flow does not stop, discontinue the hot refueling.
- m. Release the external fuel tank pre-check switches and place the master pre-check handle to the DOWN OFF position. Fuel flow should begin.

WARNING

Monitor the fuel vents on the vertical stabilizers for fuel spills. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- n. Monitor the fuel vent outlets and stop fuel flow if fuel spills from either vent outlet.

WARNING


Monitor the fuel tank pressure indicator and stop all refueling flow if the indicator shows red. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- o. Monitor the fuel tank pressure indicator during refueling.

WARNING

(F-18C/D only.) If the VENT TANK WET light illuminates, fuel may spill from the vent outlet(s). Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- p. (F-18C/D only.) Monitor the VENT TANK WET light. If it illuminates, immediately discontinue the hot refueling.
- q. Check the external fuel tank vents for airflow as the tanks fill.
- r. When the fuel flow stops, shut off the fuel at the source and disconnect the nozzle. Replace the dust cap on the SPR adaptor.
- s. Remove the grounding/bonding wires.
- t. Disconnect the intercom and close door No. 8. Do not catch the SPR dust cap chain in the door.
- u. Remove the chocks and signal the aircrew to taxi away from the area.



TO-00-25-172CL-3-008

Figure 5-1. F-18 Refueling Provisions (Sheet 1 of 2)





Figure 5-1. F-18 Refueling Provisions (Sheet 2)



TO-00-25-172CL-3-010

Figure 5-2. F-18 External Tank Safing Mechanism

CHAPTER 6

S-3 HOT REFUELING PROCEDURE

6.1 S-3 HOT REFUELING PROCEDURE.

The Single Point Receptacle (SPR) is located on the right side of the fuselage immediately aft of the main landing gear well (Figure 6-1). Manual pre-check controls and the tank pressure gauge are located in the right main wheel well “around the corner” from the SPR. The aircraft can carry 1933 gallons in four internal fuel tanks in the center wing section (inboard of the wing folds) and 265 gallons in each of two external fuel tanks. The external tanks have no pre-check capability, but can be hot refueled. Internal tanks are vented through a single outlet at the aft end of the fuselage, while the external tanks are vented at the tank bottoms. A single fuel dump (jettison) chute is located at the fuselage aft end.

6.1.1 Auxiliary Power Unit (APU). The aircraft has an on board APU with an exhaust port on the fuselage left side (near the running engine). The APU can be running during hot refueling. The right engine is shut down during hot refueling.

6.1.2 Refueling. The aircraft carries up to 46 sonobuoys that are launched from tubes on the bottom aft fuselage. Prior to refueling, these sonobuoys are safed by opening a small door just forward of the left hand sonobuoy chutes. The door has a link that operates a safing switch.

CURSORY INSPECTION.

- a. Stop the aircraft at least 50 feet short of the hot refueling area.

WARNING

Do not hot refuel with the wings folded. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- b. Signal the aircrew to spread the wings.

TO 00-25-172CL-3

- c. Signal the aircrew to shut down the right engine.
- d. Check for hot brakes.
- e. Verify all external weapons and external tanks have been safed. Ensure the external fuel tank locking indicator (Figure 6-2) is in the LOCK position.
- f. Verify the fuel dump (jettison) valve is closed.

WARNING

Avoid the tail hook area when working beneath the aircraft. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- g. Open the sonobuoy safing door (on the fuselage bottom) just forward of the left hand sonobuoy chutes. Check the safing link for integrity. (There are two linksone for holding the door and the other for operating the safing switch).
- h. Signal the aircrew to taxi to the hot refueling area.

REFUELING.

- a. Position the aircraft on the hot refueling pit.
- b. Chock and ground the aircraft. (A grounding point is located on the bottom of the fuselage about three feet aft of the nose gear door.)
- c. If available, connect the intercom (on the nose wheel door).
- d. Check that no air is flowing from the external fuel tank vents. This verifies that engine bleed air is not pressurizing the external tanks.

WARNING

Prior to pressurizing the fuel source, verify the nozzle is locked onto the aircraft by attempting to remove the nozzle with the flow handle open. If you can remove the nozzle, do not start the refueling until the nozzle is replaced. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- e. Bring the fueling equipment behind the right engine and attach the nozzle to the SPR. Open the nozzle flow handle and attempt to remove the nozzle with the flow handle in the open position.
- f. Verify that the external tank fueling switch (at the SPR) is OFF.
- g. Begin the refueling. Rotate and hold both pre-check valves to the vertical (open) position at the same time. (The switches are spring-loaded to the horizontal (closed) position). Fuel flow should stop within 20 seconds. If fuel flow does not stop, discontinue the hot refueling.
- h. After the internal fuel tanks have completed their pre-check, release the pre-check valves and position the external tank fueling switch to ON.

WARNING

Stop the hot refueling operation if the tank pressure gauge reaches the red zone. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- i. Observe the tank pressure gauge as the tanks fill.
- j. As the fuel tanks fill, check for air flowing from the vent outlets.
- k. When the tanks are full, turn off the fuel at the source and disconnect the nozzle.


TO 00-25-172CL-3

- l. Position the external tank fueling switch to OFF.
- m. Disconnect the grounding/bonding wires and the intercom. Secure the SPR panel.

WARNING


Avoid the tail hook area when working beneath the aircraft. Failure to comply could result in injury to, or death of, personnel or long term health hazards.

- n. Close the sonobuoy safing door.
- o. Remove the chocks and signal the aircrew to taxi away from area.




TO-00-25-172CL-3-011

Figure 6-1. S-3 Refueling Provisions (Sheet 1 of 2)




INSIDE RIGHT MAIN WHEEL WELL



TO-00-25-172CL-3-012

Figure 6-1. S-3 Refueling Provisions (Sheet 2)



TO-00-25-172CL-3-013

Figure 6-2. S-3 External Tank Safing Indicator

CHAPTER 7

AV-8 HOT REFUELING PROCEDURES

7.1 REFUELING/DEFUELING.

The aircraft is refueled/defueled through a standard refuel/defuel receptacle located below Door 22 on the left forward fuselage. Ground refueling controls and indicators and the intercom connection are inside Door 22. The maximum refueling pressure is 55 pound-force per square inch (PSI). All tanks are vented through the vent mast on lower right side of fuselage, below the right front nozzle. Use of the intercom is preferred, but not mandatory. The diagrams at the end of this chapter show the ground refueling provisions and the armament safing provisions.

REFUELING PRECAUTIONS.

WARNING

- Failure to comply with the precautions below could result in injury or death to personnel.
- Aviation turbine fuel is flammable and toxic to eyes, skin, and respiratory tract. Skin/eye protection is required. Avoid repeated/prolonged contact. Use only in well ventilated areas. Keep away from open flames or other sources of ignition.
 - a. Do not refuel aircraft with suspected hot brakes.
 - b. Make sure aircraft fuel servicing equipment and external electrical power source are grounded.
 - c. Make sure enough fire fighting equipment is available (Technical Order (TO) 00-25-172).
 - d. Inspect refueling nozzle locking device to make sure aircraft ground refueling receptacle is serviceable.

TO 00-25-172CL-3

- e. Make sure vent mast is not obstructed.
- f. Make sure refueling is not done within 300 feet of ground radar equipment.
- g. Make sure refueling is not done within 50 feet of other aircraft with engine(s) operating.
- h. Operation of the Auxiliary Power Unit (APU) is prohibited during normal refueling.
- i. Do not carry or wear loose metal objects, such as knives, keys, or other objects which might cause sparks.
- j. Never fuel or defuel during electrical storms.
- k. Do not carry matches or cigarette lighters.
- l. Do not wear shoes with exposed nails, metal plates or hobnails.
- m. Make sure aircraft is chocked.

NOTE

Safetied means installation of any arming lever, safety pin, electrical interrupt, plug pin, securing of armament switches and/or any applicable action which makes the specific ordnance carried safe.

- n. All ordnance will be safetied.
- o. Fuel pressure from servicing equipment should not exceed 55 PSI, during normal refueling.
- p. Make sure aircraft is receiving correct fuel (JP-4, JP-5 or JP-8).

REFUELING PROCEDURE.

- a. Attach intercom cord and determine quantity of fuel required.

- b. Observe all refueling precautions. Avoid the engine inlet.

WARNING

To prevent injury to personnel or damage to aircraft from possible static electricity discharge, all personnel involved in refueling shall dissipate static potential by gripping grounding wire before starting refueling operation and repeating frequently during refueling operation.

- c. Static bond aircraft and refueling equipment. (Bonding receptacle is on left side of the aircraft near the Single Point Receptacle (SPR).)
- d. On FUEL control panel assembly, make sure WING dump switches are in NORM position.
- e. Remove ground refuel/defuel receptacle cap. On cap equipped with locking lever, press lever to unlock cap during removal.
- f. Insert refueling/defueling nozzle in ground refuel/defuel receptacle by pushing and turning clockwise.

WARNING

To prevent spillage, resulting in possible fire and/or explosion, make sure nozzle is in locked position.

- g. Make sure refueling nozzle is fully engaged by turning clockwise until nozzle resists turning. Lock nozzle in position by positioning nozzle manual fuel shutoff lever in full open position.
- h. Inspect refueling nozzle engagement by a counterclockwise tug on nozzle handles. Determine refueling hose quick disconnect fitting engagement by pulling on hose and visual inspection.
- i. Make sure aircraft is receiving the correct fuel (JP-4, JP-5 or JP-8).
- j. Open Door 22.

TO 00-25-172CL-3

- k. If required, set EXTERNAL TANK LOCKOUT switch to LOCK-OUT position.

WARNING

To prevent injury to personnel and damage to equipment, do not refuel aircraft, if TANK OVER PRESS warning lamp is inoperative.

- l. Press-to-test TANK OVER PRESS (red) warning light for lamp operation.
- m. On external fuel control panel assembly, set LEFT and RIGHT REFUEL switches to the SHUT OFF position (toggles up).

WARNING

To prevent injury to personnel and damage to fuel system, fuel pressure from servicing equipment shall not exceed 55 PSI.

- n. Apply 55 PSI refueling pressure.

WARNING

To prevent injury to personnel and damage to equipment, do not attempt to refuel aircraft if fuel enters tanks.

- o. Make sure REFUEL VALVES are closed preventing fuel from entering fuel tanks, with refueling pressure applied.
- p. Remove 55 PSI refueling pressure.
- q. Set LEFT and RIGHT REFUEL switches to REFUEL position (toggles down).

WARNING

To prevent injury to personnel and damage to equipment, do not exceed 55 PSI refueling pressure.

- r. Apply 55 PSI refueling pressure.
- s. Make sure LEFT and RIGHT FUEL CONTENTS (green) lights are on when refueling pressure is applied.


WARNING

To prevent injury to personnel and damage to equipment, stop refueling immediately if TANK OVER PRESS (red) warning light comes on.

- t. Fuel can be stopped from entering the external tanks by setting EXT TANK LOCKOUT switch to LOCKOUT position.
- u. Monitor external fuel control panel assembly. If the tanks become overpressurized during refueling, the TANK OVER PRESS warning light will come on. If this occurs, stop refueling immediately and investigate cause.
- v. After 60 to 120 gallons of fuel have entered tanks, make sure air is venting from vent mast on lower right side of fuselage, below the right front nozzle.
- w. When tanks are full, LEFT and RIGHT FUEL CONTENTS lights will go off. If fuel flow does not stop automatically, fuel spillage from vent mast will result. Do substeps below immediately:
 - (1) Stop fuel service operation and turn off fuel servicing equipment.
 - (2) Disconnect refueling nozzle from refuel/defuel receptacle.


TO 00-25-172CL-3

- (3) Alert fire department and take action to make area safe before moving aircraft or ground support equipment.
- x. Stop refueling equipment.
- y. Verify that the correct quantity of fuel is displayed on fuel digital display indicator.
- z. Set LEFT and RIGHT REFUEL switches to flight position (toggles up).
- aa. Turn refueling nozzle counterclockwise and remove refueling nozzle. To prevent loss or damage to receptacle cap, make sure cap has engaged all three lugs on the refuel/defuel receptacle. On caps equipped with locking lever, make sure lever is flush with cap.
- ab. Inspect refueling receptacle for leakage and install receptacle cap.
- ac. Remove intercom cord and refueling unit bond wire.
- ad. Close Door 22.



TO-00-25-172CL-3-014

Figure 7-1. Refueling/Defueling Controls and Indicators (Sheet 1 of 3)



TO-00-25-172CL-3-015

Figure 7-1. Refueling/Defueling Controls and Indicators (Sheet 2)




Figure 7-1. Refueling/Defueling Controls and Indicators (Sheet 3)




Figure 7-2. LAU-7/A-5 Launcher Detent Wrench Safety Pin





Figure 7-3. ITER Ejector Unit Assembly Safety Stop Lever



TO-00-25-172CL-3-019

Figure 7-4. Aircraft 25MM Gun Safety Pin



TO-00-25-172CL-3-020

Figure 7-5. ALE-39 Ejector Rack Safety Pin

